



APPLICATION INSTRUCTIONS

Aluminium Coating

(Including Anodized-Polished or Brushed)

ONE COAT

STEP ONE:

- Clean areas to be coated with UV Supershield Metal Cleaner.
- Wipe on cleaner with soft cloth, wipe off cleaner immediately with damp cloth.
- Make sure surface is clean and dry before coating.

STEP TWO:

- Apply one coat UV Supershield . (Two Part)
- Apply with soft sponge, foam or bristle brush.

FOR OPTIMUM FINISH:

- Allow coating to dry 20-30 minutes
- Add Crosslinker (4-6 hour pot life)
- Add more coats if desired. (One of two hour intervals)

PLEASE NOTE:

- UV Supershield is available in High Gloss, Satin or Matt finish
- Do not dilute coating
- Product can be removed with UVS-X100

One coat of UV Supershield will last for years
(Fluoropolymer)

UV Supershield can be re-coated
(Will not chip, peel, crack or yellow)

OTHER APPLICATIONS:

- Stainless Steel products
- Brass
- Copper
- Silver
- Chrome
- All Aluminium

NO MORE TARNISHING OR CORRODING